

Notes:

No-Clean Fluxes can be "RO" or "RE" (with or without halides)

"OR" fluxes must be without halide (example: ORL0)

"IN" fluxes are used by plumbers (normally not used in electronics)